

ENGLISH

ONA BREEZE FAN

OPERATING INSTRUCTIONS

ONA Breeze can provide odor neutralization for rooms up to 1500 sq ft (140 sq. m.) or (500 cubic meters). Use with ONA 4L and 1L Gel containers only. Each ONA gel container will generally last from 3 - 6 weeks depending on room temperature, humidity, and fan speed.

OPERATING INSTRUCTIONS

1. Remove lid on 4 litre (1 gal) pail or jar of ONA Gel.
2. Place Breeze fan on top of a 4-liter gel container or pail by aligning the bottom mounts to the container edge.
3. Plug the power adapter (included) into the Breeze and then into a power outlet.
4. Choose desired airflow speed (high or low) for effective odor neutralization.
5. When ONA Gel is reduced to within one inch of the bottom of the pail, replace the Gel pail.

MAINTENANCE & USAGE

- Keep Breeze unit clean, and fan vents clear of anything that may restrict airflow.
- If the strength of odors in a room fluctuates, adjust fan speed to compensate.
- For best results, use Breeze in an elevated, unobstructed position such as on a table.

SAFETY INFORMATION

- ONA Breeze is designed to operate on 100 - 240 volt, 50/60 hertz alternating current.
- Operate the ONA Breeze and Gel on a level surface only.
- Do not immerse Breeze into water or liquid - shock hazard.

FAN SPECIFICATIONS

AC ADAPTER SPECIFICATIONS

Cubic Feet Per Minute	35 CFM	Input	100 - 240V ~ 50 - 60Hz
Watts	2W	Output	12.0V ~ 0.16A
Volts	110 - 240V		
Hertz	50/60Hz		
Dimensions	9.25" L x 2.625" W x 9.75" H		
Unit Weight	1.2 lbs / 0.54 kg		

Made in China

WARRANTY

- 1-year limited warranty
- Limited warranty covers product defects and workmanship. Does not cover physical damage or wear and tear beyond the normal intended use.
- Original proof of purchase required



DOWNLOAD INSTRUCTIONS:

عربي, Český, Deutsch, English, Ελληνικά, Español, עברית, Italiano, Język Polski,
Le Français, Nederlands, Português, Russkiy, Svenska, Suomi

www.onaonline.com/downloads